



■ Thermal Energy ■ Flow Metering ■

Manual

Radio Modem



Supercom 636

Issue:

Document:

Manufacturer:

Rev. 010312

Manual Supercom 636 R+W rev. 010312

Sontex SA

2605 Sonceboz, Switzerland

Phone: +41 32 488 30 00

Fax: +41 32 488 30 01

Email: @sontex.ch

Internet: .sontex.ch

Revision

Issue	Date	Author	Description
200309	20.03.09	NU	In accordance with software version 0.1.5
200409	20.04.09	NU	In accordance with software version 0.1.6
230409	23.04.09	MS	General Revue and approval
040609	04.06.09	NU	In accordance with software version 0.1.8
300609	30.06.09	MS	General update, software version 0.1.12
160709	16.07.09	SV	Removed writing concept
250809	25.08.09	NU	Update Annex E (Writing 556)
160909	16.09.09	SV	Add chapter 3.1.6 (using the accumulators)
051109	05.11.09	SV	Adapted length of field in PDF file (page 11)
150210	15.02.10	SV	Add information related to xml files
260410	26.04.10	SV	Error in status byte description (page 11)
211010	21.10.10	SV	Add 656 & 541. Adapted writing factor KC for 556
200411	20.04.11	SV	Add information for 449
010312	01.03.12	SV	Add entry for 539 (write) + change finalize parametrize 556

Table of Contents

1.	General.....	4
1.1	Introduction	4
1.2	Field of application of modem	4
1.3	Necessary configuration.....	4
2.	Scope of delivery	5
3.	How to use.....	6
3.1	Introduction	6
3.1.1	USB	6
3.1.2	Switch ON/OFF the modem	6
3.1.3	Bluetooth.....	6
3.1.4	LED display.....	7
3.1.5	Charging accumulators	8
3.1.6	Using the accumulators.....	8
4.	Communication	9
4.1	Introduction	9
4.1.1	Reading concept.....	9
4.1.2	Detailed reading steps	10
5.	Utilities	13
5.1	Firmware Update.....	13
6.	Annex A	14
6.1	Detailed reading process schematics.....	14
7.	Annex B	15
7.1	Add entry to device list to read a device.....	15
8.	Annex C	16
8.1	Encoded frames Radio Pulse Adapter 540	16
8.2	Encoded frames calculator Supercal 531/449 (rsp106 and rsp107)	21
9.	Annex D	25
9.1	Detailed writing process schematics	25
10.	Annex E.....	26
10.1	Add entry to device list to write a device	26
10.2	Writing standard products	26
10.3	Writing the heat cost allocator 502 / 552	27
10.4	Writing the heat cost allocator Sontex 556.....	28
10.5	Writing the radio pulse adapter 540	32


1. General

1.1 Introduction

This user guide describes the operation and the use of the radio modem 636. It is addressed to all users as well as to application engineers.

1.2 Field of application of modem

The external peripheral radio modem Supercom 636 is suitable for a connection to PC or Pocket PC with USB or Bluetooth. It allows the read out of meters per radio. The modem works at a frequency of 433.82 MHz and supports the protocols MFD and Radian 0.



1.3 Necessary configuration

The radio modem Supercom 636 can be connected to any system (PC, Laptop or Pocket PC) which has the following characteristics:

- USB port
- or
- Bluetooth

2. Scope of delivery

Content set radio modem Supercom 636:

- Radio modem Supercom 636 with belt clip
- 3 accumulators 1.2V type AAA (1000mAh)
- Radio antenna
- User manual
- CD with
 - User manual (pdf)
 - USB driver
 - PDA SW Sontex916
 - Firmware update PC SW Tools636
 - Road Creator PC SW Tools916
- USB cable (mini USB - USB A male)
- USB charger (230VAC and 12VDC)

! Accumulators are not charged !
! Initial charge necessary !
! 8 h minimum !

3. How to use

3.1 Introduction

There're two possibilities to communicate with the modem Supercom 636: USB or Bluetooth. Both are using M-Bus protocol.

3.1.1 USB

- Speed: 38'400 bauds
- Bits: 8 bits
- Parity: even
- Stop bit: 1

The USB driver (virtual com port) you find on the CD delivered with the set radio modem Supercom 636 or on the internet at the following address: [://www.ftdichip.com/FTDrivers.htm](http://www.ftdichip.com/FTDrivers.htm)

This driver is requested only at the first connection of the radio modem to the PC. Thereafter the communication will then be available from a com port (COMx).

3.1.2 Switch ON/OFF the modem

With the orange button the radio modem Supercom 636 can be switched ON and OFF. After 10 minutes of inactivity the radio modem Supercom 636 shuts down by itself.

3.1.3 Bluetooth

For the start up the modem must first connect with the remote system.
To establish connection the following steps must be followed and completed:

- Switch ON the radio modem Supercom 636 over the orange button.
The blue LED indicates that the modem Supercom 636 is visible to other Bluetooth devices.
- On the remote device (PDA) search for Bluetooth devices in your area.
Check the manual of your remote device for instructions.
- Once the remote device found the modem radio Supercom 636 the remote device will display its name and serial number (e.g. Supercom 636 S/N: 08094002).
- Select it and enter the following password if necessary: 0000
- Depending on the remote device you have to indicate a COM port number for the outgoing communication. Please check the manual of your remote device for instructions. This task must only be performed once.
- Once the remote device opens a communication port to the radio modem Supercom 636 the blue LED is blinking as long the port is open. When the port is closed the blue LED is on but not blinking.

3.1.4 LED display

There're four LEDs on the front of the device.



- Link : (Blue)

Conditions	LED state
The modem is ON	ON
A Bluetooth communication port is opened.	Blinking 0.25s every 2s
The modem is OFF	OFF

- Charge: (Red)

Conditions	LED state
Accumulators charged	OFF
Low power	Blinking 0.25s every 3s
** Near empty	1 blink
Charging	ON

** If the accumulators are near empty the device shuts down by itself.

- Tx : (yellow)


Conditions	LED state
A byte is transmitted via radio	0.25s per byte

- Rx : (yellow)

Conditions	LED state
A byte is received via radio	0.25s per byte

3.1.4.1 Switch ON sequence

By turning ON the Supercom 636, the following LEDs sequence is running:



If another sequence is running contact your local Sontex agent or the Sontex technical support.
(See last page of this document for contacts).

3.1.5 Charging accumulators

The radio modem Supercom 636 needs 3 accumulators 1.2V type AAA Ni-Mh (1000mAh). In case of replacing the accumulators we recommend to always use products of the same supplier of accumulators.

Only use Ni-Mh accumulators.

Disposal of battery and device

It is mandatory to dispose of used accumulators and the radio modem Supercom 636 environmental friendly or to return it after use to the manufacturer for appropriate disposal to ensure that the components are recycled in accordance with the battery and electronic scrap regulations. If you decide to dispose of the battery or the device yourself get proper information about recycling possibilities locally.



The radio modem Supercom 636 can be charged by USB on a host PC hub (500mA) or with the charger (recommended) delivered with the set. The red LED indicates the charging mode (see 3.1.4.)

The device must be charged first before a first use (Minimum 8 hours).

Once the device is fully charged it will switch OFF automatically.

3.1.6 Using the accumulators

Accumulators are self discharging over time, accumulators not used must be charged at least every 6 months.

4. Communication

4.1 Introduction

The radio modem Supercom 636 uses the M-Bus protocol according to EN1434 to communicate. It supports primary and secondary addressing. For more detailed information, please refer to the M-Bus documentation available on the internet: [://www.m-bus.com/](http://www.m-bus.com/)

4.1.1 Reading concept

The radio modem is like 2 separate devices:

1. The modem itself
2. The device to be read

Each device can be accessed with its secondary address (serial number) or primary address:

- Primary address for modem 636: **251**
- Primary address for device to be read: **254**

The 636 has a local memory which can contain the information (address and readout method) of the radio device to be read (maximum one).

The 636 contains two frames.

1. Modem information
2. Device to read information (address and readout method) if present

To read a radio device (e.g Radio module Supercom 580) the necessary information (radio address and readout method) must be introduced into the local memory with the

command "SND_UD"

containing the field "Add entry to device list".

The radio communication is started with the

command "SND_UD"

containing the field "Start read radio process".

Sending a request to the radio modem Supercom 636 during the radio process will return a "busy" frame. (3. / page 12).

To read the result send a request "REQ_UD2" to the device address "254".

4.1.2 Detailed reading steps

See Annex A, page 14, for the detailed reading process schematic.

1. Request the frame “Rsp1” with a “REQ_UD2” (Addr.251).

Frame “Rsp1” (Contains modem information)

	Field	Frame bytes in hex (Note 1)	Coding	Comment
Start	Start, Length	68, Le Le, 68		
	Control	08		Respond with user data, RSP_UD
	Address	FD or FB		
User data	Control Information	72		Variable structure respond
	Identification number	xx xx xx xx	A, 32 bits	
	Manufacturer ID	EE 4D	C, 16 bits	"SON"
	Version of meter	14	C, 8 bits	
	Device type	0E	D, 8 bits	Bus / System component
	Access number	xx	C, 8 bits	
	Status	st	Ds, 8 bits	
	Signature (not used)	00 00	C, 16 bits	
	Detailed errors	02, FD 17, er er	D, 16 bits	
	Current date & time	04, 6D, xx xx xx xx	F, 32 bits	
	Parameters flags	01, FD 66, pp	D, 8 bits	
	Internal version	0C, FD 0F, xx xx xx xx	A, 32 bits	
	Hardware version	02, FD 0D, xx xx	C, 16 bits	
	Fabrication Number	0C, 78, xx xx xx xx	A, 32 bits	
	More records in next telegram	mo		Start of manufacturer specific data
End	Check Sum	cs		
	Stop	16		

Keys

	Optional record	
xx	Value LSByte first	
yy	Value MSByte first	
ch	ASCII character	
cs	The value of Check Sum is calculated from arithmetical sum modulo 256 of each byte of the frame except the fields: Start, Length (if any), Check Sum and Stop.	
er er	Detailed errors 636	M-Bus standard
	bit0 †	Tamper
	bit1 Accumulators low	Battery low
	bit2 †	External alarm
	bit3 †	Battery cut
	bit7..4 †	RSSI
	bit8 SND_UD frame: unknown CI.	
	bit9 SND_UD frame, structured write: unknown field.	
	bit10 †	
	bit11 SND_UD frame, structured write: bad field size.	
	bit12 SND_UD frame, structured write: memory overflow.	
	bit13 †	
	bit14 Invalid time clock	
	bit15 Last radio process error	
Le	Length of the M-Bus frame. The fields Start, Length, Check Sum and Stop (6 bytes) are not included in the calculation of the Length field. The Length field is repeated twice preceded and followed by the Start field 68h.	
LS	Length of ASCII character string Warning: according to the M-Bus standard, the first byte following the length byte is the rightmost character of the string, and the last byte is the leftmost character.	
mo	More records in next telegram :	
	0Fh no	
	1Fh yes	
pp	Parameter flags	
	bit0	When the selected device is in the device list, but not yet read :
		0: send an ""empty"" RSP_UD (with just the 12 bytes header)
		1: do not send anything
st	Status 636	M-Bus standard
	bit1..0 Application	Application
	00b No error	No error
	01b †	Application busy
	10b Any application error	Any application error
	11b †	Reserved
	bit2 Accumulators low	Power low
	bit3 †	Permanent error
	bit4 †	Temporary error
	bit5 †	Manufacturer specific
	bit6 Invalid time clock	Manufacturer specific
	bit7 Last radio process error	Manufacturer specific

† Not used.

2. To read a device send the command “SND_UD” (Addr.251):

	Field	Frame bytes in hex (Note 1)	Coding	Comment
Start	Start, Length	68, Le Le, 68		
	Control	73 53		Send user data to slave, SND_UD
	Address	FD or FB		
User data	Control Information	51		Stuctured write telegram
	Current date & time	04, 6D, xx xx xx xx	F, 32 bits	
	Add entry to device list	0D, FF 16, Ls xx	LVAR	§
	Parameters flags	01, FD 66, pp	D, 8 bits	
	Start read radio process	01, FF, 24, 00		§
	Start write radio process	01, FF, 24, 01		§
End	Check Sum	cs		
	Stop	16		
Symbols				
‡ Function: 0=instantaneous, 1=maximum, 2=minimum, 3=during error state				
§ manufacturer specific VIFE				
Notes				
1. For non hexadecimal or lower case digits see the detailed description in the Keys sheet				

Read process:

The field “Current date & time” must be added in the “Add entry to device list” if bit7”Adjust device clock” = 1 of Options byte.

The field “Add entry to device list” is detailed in Annex B.

The field “Start read radio process” starts the read radio communication.

Write process:

The field “Add entry to device list” is detailed in Annex E.

The field “Start write radio process” starts the write radio communication.

3. Sending the command “REQ_UD2” if the radio process is in progress, the radio modem Supercom 636 is communicating by radio with the device, will return a “busy” frame:

	Field	Frame bytes in hex	
Header	Start, Length	68, 04 04, 68	See Note 1
	Control	08	Respond with user data, RSP_UD
	Address	FD or FB	
	Control Information	70	Repport of application errors
		08	Application to busy for handling readout request
End	Check Sum	xx	
	Stop	16	

4. If the modem is no longer busy send the command “REQ_UD2” (Addr.254) to readout the device frame.
5. If a radio problem occurs (e.g. no answer of the device), the frame RSP_UD of the device contains only the header without data or doesn’t send anything at all.
See parameter flags “pp” in the frame Rsp1 of the modem.
Also check bit7 of status byte “st” in the frame Rsp1 of the modem.

5. Utilities


5.1 Firmware Update

The firmware of the modem Supercom 636 can be updated by the USB interface from a computer with the software Tools636.



6. Annex A

6.1 Detailed reading process schematics



7. Annex B

7.1 Add entry to device list to read a device

		Identification Number	Manufacturer ID	Generation of Meter	Measured Media	Radio Address	Radio Device Type	Options	Maximal Frame Number	Application Reset Subcode	Date of Last Successful Reading
Type		A	C	C	D	A	C	D	C	D	G
Bytes		4	2	1	1	4	1	1	1	1	2
Notes		a, e	a, e	a	a	b, e	b	b	b	b	c, e
Device type	Values to read										
HCA 502, 502S, 552	All values	xxxxxxxxh	4DEEh	4	08h	xxxxxxxxh	0	80h	01h	00h	0101h
HCA 502S, 552	All values (compact reading)	xxxxxxxxh	4DEEh	4	08h	xxxxxxxxh	0	80h	01h	01h	0101h
Supercal 539 or 539+	Current values	xxxxxxxxh	4DEEh	4	04h	xxxxxxxxh	1	80h	01h	00h	0101h
Supercal 539+	+ monthly energy	xxxxxxxxh	4DEEh	4	04h	xxxxxxxxh	1	80h	02h	00h	0101h
Supercal 539+	+ monthly volume	xxxxxxxxh	4DEEh	4	04h	xxxxxxxxh	1	80h	03h	00h	0101h
Supercal 539+	All values	xxxxxxxxh	4DEEh	4	04h	xxxxxxxxh	1	80h	05h	00h	0101h
540 pulses	All values	xxxxxxxxh	4DEEh	1	00h	xxxxxxxxh	2	80h	04h	00h	0101h
531 / 449	frames 1, 2, 3, 4	xxxxxxxxh	4DEEh	12	04h	xxxxxxxxh	3	80h	04h	00h	0101h
531 / 449	frames 1, 2, 3, 4, 5, 10	xxxxxxxxh	4DEEh	12	04h	xxxxxxxxh	3	80h	06h	01h	0101h
531 / 449	frames 106, 107	xxxxxxxxh	4DEEh	12	04h	xxxxxxxxh	3	80h	04h	02h	0101h
531 / 449	frames 56, 57, 58, 59	xxxxxxxxh	4DEEh	12	04h	xxxxxxxxh	3	80h	04h	03h	0101h
590 WCA	All values	xxxxxxxxh	38AFh	4	07h	xxxxxxxxh	4	81h	01h	00h	0101h
580 Water counter	All values	xxxxxxxxh	4DEEh	10	07h	xxxxxxxxh	4	80h	01h	00h	0101h
581 Water counter	All values	xxxxxxxxh	4DEEh	20	07h	xxxxxxxxh	4	80h	01h	00h	0101h
556 HCA	All values	xxxxxxxxh	4DEEh	16	08h	xxxxxxxxh	5	B1h	02h	00h	0101h
541 pulses	All values	xxxxxxxxh	4DEEh	10	00h	xxxxxxxxh	6	90h	03h	00h	0101h
656 repeater	All values	xxxxxxxxh	4DEEh	30	0Eh	xxxxxxxxh	6	00h	01h	00h	0101h

Notes

- a This value is part of the M-Bus secondary address used to access the data of a device stored in 636. It is updated by 636 according to the value really read from the device by radio.
- b This value is used to access the device by radio. It is never modified by the 636 itself.
- c The date 1.1.2000 means ""not yet successful read"", coded in M-Bus G type: 0101h
- e Multibytes values are transmitted with LSB first.

Options

bit7 Adjust device clock: 0=no, 1=yes

8. Annex C

8.1 Encoded frames Radio Pulse Adapter 540

Rsp_1

	Field	Frame bytes in hex (Note 1)	Coding	Comment
Start	Start, Length	68, Le Le, 68		
	Control	08		Respond with user data, RSP_UD
	Address	xx		
User data	Control Information	72		Variable structure respond
	Identification number	xx xx xx xx	A, 32 bits	
	Manufacturer ID	EE 4D	C, 16 bits	"SON"
	Version of meter	01	C, 8 bits	
	Device type	00	D, 8 bits	
	Access number	xx	C, 8 bits	
	Status	st	Ds, 8 bits	
	Signature (not used)	00 00	C, 16 bits	
	Current date & time	04, 6D, xx xx xx xx	F, 32 bits	
	Identification number	0C, 79, xx xx xx xx	A, 32 bits	
	Medium string	0D, FD 09, 03, me me me	LVAR	3 char
	Units string	0D, FD 67, 05, un un un un un	LVAR	5 char
	Units factor	05, EE 76, xx xx xx xx	H, 32 bits	dimensionless
	Totalizer initial value	44, 6E, xx xx xx xx	B, 32 bits	dimensionless
	Info string	0D, FD 0C, 18, ch	LVAR	24 char
	Totalizer current value	04, 6E, xx xx xx xx	B, 32 bits	
	Units stored at month - 1	84 01, 6E, xx xx xx xx	B, 32 bits	dimensionless
	Units stored at month - 2	C4 01, 6E, xx xx xx xx	B, 32 bits	dimensionless
	Units stored at month - 3	84 02, 6E, xx xx xx xx	B, 32 bits	dimensionless
	Units stored at month - 4	C4 02, 6E, xx xx xx xx	B, 32 bits	dimensionless
	Units stored at month - 5	84 03, 6E, xx xx xx xx	B, 32 bits	dimensionless
	Units stored at month - 6	C4 03, 6E, xx xx xx xx	B, 32 bits	dimensionless
	Units stored at month - 7	84 04, 6E, xx xx xx xx	B, 32 bits	dimensionless
	Units stored at month - 8	C4 04, 6E, xx xx xx xx	B, 32 bits	dimensionless
	Units stored at month - 9	84 05, 6E, xx xx xx xx	B, 32 bits	dimensionless
	Units stored at month - 10	C4 05, 6E, xx xx xx xx	B, 32 bits	dimensionless
	Units stored at month - 11	84 06, 6E, xx xx xx xx	B, 32 bits	dimensionless
	Units stored at month - 12	C4 06, 6E, xx xx xx xx	B, 32 bits	dimensionless
	Units stored at month - 13	84 07, 6E, xx xx xx xx	B, 32 bits	dimensionless
	Units stored at month - 14	C4 07, 6E, xx xx xx xx	B, 32 bits	dimensionless
	Units stored at month - 15	84 08, 6E, xx xx xx xx	B, 32 bits	dimensionless
	Units stored at month - 16	C4 08, 6E, xx xx xx xx	B, 32 bits	dimensionless
	More records in next telegram	mo		Start of manufacturer specific data
End	Check Sum	cs		
	Stop	16		

Rsp_2

	Field	Frame bytes in hex (Note 1)	Coding	Comment
Start	Start Length	68, Le Le, 68		
	Control	08		Respond with user data, RSP_UD
	Address	xx		
User data	Control Information	72		Variable structure respond
	Identification number	xx xx xx xx	A, 32 bits	
	Manufacturer ID	EE 4D	C, 16 bits	"SON"
	Version of meter	01	C, 8 bits	
	Device type	00	D, 8 bits	
	Access number	xx	C, 8 bits	
	Status	st	Ds, 8 bits	
	Signature (not used)	00 00	C, 16 bits	
	Identification number	8C 40, 79, xx xx xx xx	A, 32 bits	
	Medium string	8D 40, FD 09, 03, me me me	LVAR	
	Units string	8D 40, FD 67, 05, un un un un un	LVAR	3 char
	Units factor	85 40, EE 76, xx xx xx xx	H, 32 bits	5 char
	Totalizer initial value	C4 40, 6E, xx xx xx xx	B, 32 bits	dimensionless
	Info string	8D 40, FD 0C, 18, ch ch ch ch ch ch ch ch ch ch ch ch ch ch ch ch	LVAR	dimensionless
	Totalizer current value	84 40, 6E, xx xx xx xx	B, 32 bits	24 char
	Units stored at month - 1	84 41, 6E, xx xx xx xx	B, 32 bits	
	Units stored at month - 2	C4 41, 6E, xx xx xx xx	B, 32 bits	dimensionless
	Units stored at month - 3	84 42, 6E, xx xx xx xx	B, 32 bits	dimensionless
	Units stored at month - 4	C4 42, 6E, xx xx xx xx	B, 32 bits	dimensionless
	Units stored at month - 5	84 43, 6E, xx xx xx xx	B, 32 bits	dimensionless
	Units stored at month - 6	C4 43, 6E, xx xx xx xx	B, 32 bits	dimensionless
	Units stored at month - 7	84 44, 6E, xx xx xx xx	B, 32 bits	
	Units stored at month - 8	C4 44, 6E, xx xx xx xx	B, 32 bits	
	Units stored at month - 9	84 45, 6E, xx xx xx xx	B, 32 bits	
	Units stored at month - 10	C4 45, 6E, xx xx xx xx	B, 32 bits	
	Units stored at month - 11	84 46, 6E, xx xx xx xx	B, 32 bits	
	Units stored at month - 12	C4 46, 6E, xx xx xx xx	B, 32 bits	
	Units stored at month - 13	84 47, 6E, xx xx xx xx	B, 32 bits	
	Units stored at month - 14	C4 47, 6E, xx xx xx xx	B, 32 bits	
	Units stored at month - 15	84 48, 6E, xx xx xx xx	B, 32 bits	
	Units stored at month - 16	C4 48, 6E, xx xx xx xx	B, 32 bits	
	More records in next telegram	mo		Start of manufacturer specific data
End	Check Sum	cs		
	Stop	16		

Rsp_3

	Field	Frame bytes in hex (Note 1)	Coding	Comment	
Start	Start, Length	68, Le Le, 68			
	Control	08		Respond with user data, RSP_UD	
	Address	xx			
User data	Control Information	72		Variable structure respond	
	Identification number	xx xx xx xx	A, 32 bits		
	Manufacturer ID	EE 4D	C, 16 bits	"SON"	
	Version of meter	01	C, 8 bits		
	Device type	00	D, 8 bits		
	Access number	xx	C, 8 bits		
	Status	st	Ds, 8 bits		
	Signature (not used)	00 00	C, 16 bits		
	Identification number	8C 80 40, 79, xx xx xx xx	A, 32 bits		
	Medium string	8D 80 40, FD 09, 03, me me me	LVAR		
	Units string	8D 80 40, FD 67, 05, un un un un un	LVAR	3 char	
	Units factor	85 80 40, EE 76, xx xx xx xx	H, 32 bits	5 char	
	Totalizer initial value	C4 80 40, 6E, xx xx xx xx	B, 32 bits	dimensionless	
	Info string	8D 80 40, FD 0C, 18, ch	LVAR	dimensionless	
	Totalizer current value	84 80 40, 6E, xx xx xx xx	B, 32 bits	24 char	
	Units stored at month - 1	84 81 40, 6E, xx xx xx xx	B, 32 bits		
	Units stored at month - 2	C4 81 40, 6E, xx xx xx xx	B, 32 bits	dimensionless	
	Units stored at month - 3	84 82 40, 6E, xx xx xx xx	B, 32 bits	dimensionless	
	Units stored at month - 4	C4 82 40, 6E, xx xx xx xx	B, 32 bits	dimensionless	
	Units stored at month - 5	84 83 40, 6E, xx xx xx xx	B, 32 bits	dimensionless	
	Units stored at month - 6	C4 83 40, 6E, xx xx xx xx	B, 32 bits	dimensionless	
	Units stored at month - 7	84 84 40, 6E, xx xx xx xx	B, 32 bits		
	Units stored at month - 8	C4 84 40, 6E, xx xx xx xx	B, 32 bits		
	Units stored at month - 9	84 85 40, 6E, xx xx xx xx	B, 32 bits		
	Units stored at month - 10	C4 85 40, 6E, xx xx xx xx	B, 32 bits		
	Units stored at month - 11	84 86 40, 6E, xx xx xx xx	B, 32 bits		
	Units stored at month - 12	C4 86 40, 6E, xx xx xx xx	B, 32 bits		
	Units stored at month - 13	84 87 40, 6E, xx xx xx xx	B, 32 bits		
	Units stored at month - 14	C4 87 40, 6E, xx xx xx xx	B, 32 bits		
	Units stored at month - 15	84 88 40, 6E, xx xx xx xx	B, 32 bits		
	Units stored at month - 16	C4 88 40, 6E, xx xx xx xx	B, 32 bits		
	More records in next telegram	mo		Start of manufacturer specific data	
	End	Check Sum	cs		
		Stop	16		

Rsp_4

	Field	Frame bytes in hex (Note 1)	Coding	Comment
Start	Start, Length	68, Le Le, 68		
	Control	08		Respond with user data, RSP_UD
	Address	xx		
User data	Control Information	72		Variable structure respond
	Identification number	xx xx xx xx	A, 32 bits	
	Manufacturer ID	EE 4D	C, 16 bits	"SON"
	Version of meter	01	C, 8 bits	
	Device type	00	D, 8 bits	
	Access number	xx	C, 8 bits	
	Status	st	Ds, 8 bits	
	Signature (not used)	00 00	C, 16 bits	
	Identification number	8C C0 40, 79, xx xx xx xx	A, 32 bits	
	Medium string	8D C0 40, FD 09, 03, me me me	LVAR	
	Units string	8D C0 40, FD 67, 05, un un un un un	LVAR	3 char
	Units factor	85 C0 40, EE 76, xx xx xx xx	H, 32 bits	5 char
	Totalizer initial value	C4 C0 40, 6E, xx xx xx xx	B, 32 bits	dimensionless
	Info string	8D C0 40, FD 0C, 18, ch	LVAR	dimensionless
	Totalizer current value	84 C0 40, 6E, xx xx xx xx	B, 32 bits	24 char
	Units stored at month - 1	84 C1 40, 6E, xx xx xx xx	B, 32 bits	
	Units stored at month - 2	C4 C1 40, 6E, xx xx xx xx	B, 32 bits	dimensionless
	Units stored at month - 3	84 C2 40, 6E, xx xx xx xx	B, 32 bits	dimensionless
	Units stored at month - 4	C4 C2 40, 6E, xx xx xx xx	B, 32 bits	dimensionless
	Units stored at month - 5	84 C3 40, 6E, xx xx xx xx	B, 32 bits	dimensionless
	Units stored at month - 6	C4 C3 40, 6E, xx xx xx xx	B, 32 bits	dimensionless
	Units stored at month - 7	84 C4 40, 6E, xx xx xx xx	B, 32 bits	
	Units stored at month - 8	C4 C4 40, 6E, xx xx xx xx	B, 32 bits	
	Units stored at month - 9	84 C5 40, 6E, xx xx xx xx	B, 32 bits	
	Units stored at month - 10	C4 C5 40, 6E, xx xx xx xx	B, 32 bits	
	Units stored at month - 11	84 C6 40, 6E, xx xx xx xx	B, 32 bits	
	Units stored at month - 12	C4 C6 40, 6E, xx xx xx xx	B, 32 bits	
	Units stored at month - 13	84 C7 40, 6E, xx xx xx xx	B, 32 bits	
	Units stored at month - 14	C4 C7 40, 6E, xx xx xx xx	B, 32 bits	
	Units stored at month - 15	84 C8 40, 6E, xx xx xx xx	B, 32 bits	
	Units stored at month - 16	C4 C8 40, 6E, xx xx xx xx	B, 32 bits	
	More records in next telegram	mo		Start of manufacturer specific data
	End	Check Sum	cs	
Stop		16		

Notes

Medium

me		ASCII characters (3x)
	«ELE»	electricity
	«GAS»	gas
	«HCA»	heat cost allocator
	«HEA»	heat
	«HWA»	hot water
	«OIL»	oil
	«STE »	steam
	«WAT»	water
	«OTH»	other
	« »	unknown medium

Units

un		ASCII characters (5x)
	«Imp»	impuls
	«J»	Joules
	«kJ»	kilo Joules
	«MJ»	Mega Joules
	«l»	liter
	«m3»	cubic meter
	«Wh»	Watt hour
	«kWh»	kilo Watt hour
	«MWh»	Mega Watt hour
	« »	unknown unit

Information

ch		ASCII characters (24x)
	« »	all what you like

mo	More records in next telegram :	
	0F	no
	1F	yes

8.2 Encoded frames calculator Supercal 531/449 (rsp106 and rsp107)

Rsp_1

	Field	Frame bytes in hex (Note 1)	Coding	Comment
Start	Start, Length	68, Le Le, 68		
	Control	08		Respond with user data, RSP_UD
	Address	xx		
User data	Control Information	72		Variable structure respond
	Identification number	xx xx xx xx	A, 32 bits	
	Manufacturer ID	EE 4D	C, 16 bits	"SON"
	Version of meter	00	C, 8 bits	
	Device type	dt	D, 8 bits	
	Access number	xx	C, 8 bits	
	Status	st	Ds, 8 bits	
	Signature (not used)	00 00	C, 16 bits	
	Detailed errors	02, FD 17, er er	D, 16 bits	
	Energy totalizer heating	04, en en, xx xx xx xx	B, 32 bits	
	Volume totalizer	04, vo vo, xx xx xx xx	B, 32 bits	
	Energy totalizer tarif 1	84 10, en en, xx xx xx xx	B, 32 bits	
	Energy totalizer tarif 2	84 20, en en, xx xx xx xx	B, 32 bits	
	Energy totalizer stored at ST 1	C4 84 01, en en, xx xx xx xx	B, 32 bits	
	Energy stored at month - 1	44, en en, xx xx xx xx	B, 32 bits	
	Energy stored at month - 2	84 01, en en, xx xx xx xx	B, 32 bits	
	Energy stored at month - 3	C4 01, en en, xx xx xx xx	B, 32 bits	
	Energy stored at month - 4	84 02, en en, xx xx xx xx	B, 32 bits	
	Energy stored at month - 5	C4 02, en en, xx xx xx xx	B, 32 bits	
	Energy stored at month - 6	84 03, en en, xx xx xx xx	B, 32 bits	
	Energy stored at month - 7	C4 03, en en, xx xx xx xx	B, 32 bits	
	Energy stored at month - 8	84 04, en en, xx xx xx xx	B, 32 bits	
	Energy stored at month - 9	C4 04, en en, xx xx xx xx	B, 32 bits	
	Energy stored at month - 10	84 05, en en, xx xx xx xx	B, 32 bits	
	Energy stored at month - 11	C4 05, en en, xx xx xx xx	B, 32 bits	
	Energy stored at month - 12	84 06, en en, xx xx xx xx	B, 32 bits	
	Energy stored at month - 13	C4 06, en en, xx xx xx xx	B, 32 bits	
	Energy stored at month - 14	84 07, en en, xx xx xx xx	B, 32 bits	
	More records in next telegram	mo		Start of manufacturer specific data
End	Check Sum	cs		
	Stop	16		

Rsp_2

	Field	Frame bytes in hex (Note 1)	Coding	Comment
Start	Start, Length	68, 1e 1e, 68		
	Control	08		Respond with user data, RSP_UD
	Address	xx		
	Control Information	72		Variable structure respond
User data	Identification number	xx xx xx xx	A, 32 bits	
	Manufacturer ID	EE 4D	C, 16 bits	"SON"
	Version of meter	00	C, 8 bits	
	Device type	dt	D, 8 bits	
	Access number	xx	C, 8 bits	
	Status	st	Ds, 8 bits	
	Signature (not used)	00 00	C, 16 bits	
	Energy totalizer 1 stored at month - 1	C4 10, en en, xx xx xx xx	B, 32 bits	
	Energy totalizer 1 stored at month - 2	84 11, en en, xx xx xx xx	B, 32 bits	
	Energy totalizer 1 stored at month - 3	C4 11, en en, xx xx xx xx	B, 32 bits	
	Energy totalizer 1 stored at month - 4	84 12, en en, xx xx xx xx	B, 32 bits	
	Energy totalizer 1 stored at month - 5	C4 12, en en, xx xx xx xx	B, 32 bits	
	Energy totalizer 1 stored at month - 6	84 13, en en, xx xx xx xx	B, 32 bits	
	Energy totalizer 1 stored at month - 7	C4 13, en en, xx xx xx xx	B, 32 bits	
	Energy totalizer 1 stored at month - 8	84 14, en en, xx xx xx xx	B, 32 bits	
	Energy totalizer 1 stored at month - 9	C4 14, en en, xx xx xx xx	B, 32 bits	
	Energy totalizer 1 stored at month - 10	84 15, en en, xx xx xx xx	B, 32 bits	
	Energy totalizer 1 stored at month - 11	C4 15, en en, xx xx xx xx	B, 32 bits	
	Energy totalizer 1 stored at month - 12	84 16, en en, xx xx xx xx	B, 32 bits	
	Energy totalizer 1 stored at month - 13	C4 16, en en, xx xx xx xx	B, 32 bits	
	Energy totalizer 1 stored at month - 14	84 17, en en, xx xx xx xx	B, 32 bits	
	Power maximum stored at - 1	D5 82 03, 2B, xx xx xx xx	H, 32 bits	
	Power maximum stored at - 2	95 83 03, 2B, xx xx xx xx	H, 32 bits	
	Power maximum stored at - 3	D5 83 03, 2B, xx xx xx xx	H, 32 bits	
	Power maximum stored at - 4	95 84 03, 2B, xx xx xx xx	H, 32 bits	
	Power maximum stored at - 5	D5 84 03, 2B, xx xx xx xx	H, 32 bits	
	Power maximum stored at - 6	95 85 03, 2B, xx xx xx xx	H, 32 bits	
	Power maximum stored at - 7	D5 85 03, 2B, xx xx xx xx	H, 32 bits	
	Power maximum date/time stored at - 1	C4 82 03, 6D, xx xx xx xx	F, 32 bits	
	Power maximum date/time stored at - 2	84 83 03, 6D, xx xx xx xx	F, 32 bits	
	Power maximum date/time stored at - 3	C4 83 03, 6D, xx xx xx xx	F, 32 bits	
	Power maximum date/time stored at - 4	84 84 03, 6D, xx xx xx xx	F, 32 bits	
	Power maximum date/time stored at - 5	C4 84 03, 6D, xx xx xx xx	F, 32 bits	
	Power maximum date/time stored at - 6	84 85 03, 6D, xx xx xx xx	F, 32 bits	
	Power maximum date/time stored at - 7	C4 85 03, 6D, xx xx xx xx	F, 32 bits	
	More records in next telegram	mo		Start of manufacturer specific data
End	Check Sum	cs		
	Stop	16		

Rsp_3

	Field	Frame bytes in hex (Note 1)	Coding	Comment
Start	Start, Length	68, Le Le, 68		
	Control	08		Respond with user data, RSP_UD
	Address	xx		
User data	Control Information	72		Variable structure respond
	Identification number	xx xx xx xx	A, 32 bits	
	Manufacturer ID	EE 4D	C, 16 bits	"SON"
	Version of meter	00	C, 8 bits	
	Device type	dt	D, 8 bits	
	Access number	xx	C, 8 bits	
	Status	st	Ds, 8 bits	
	Signature (not used)	00 00	C, 16 bits	
	Fabrication Number MET	0C, 78, xx xx xx xx	A, 32 bits	
	Fabrication Number MIO	8C C0 C0 40, 78, xx xx xx xx	A, 32 bits	
	Current date & time	04, 6D, xx xx xx xx	F, 32 bits	
	Power	05, 2B, xx xx xx xx	H, 32 bits	[W]
	Flow	05, 3E, xx xx xx xx	H, 32 bits	[m3/h]
	Days without energy	02, FF 05, xx xx	C, 16 bits	[days]
	Days without flow	02, FF 06, xx xx	C, 16 bits	[days]
	High temperature	05, 5B, xx xx xx xx	H, 32 bits	[°C]
	Low temperature	05, 5F, xx xx xx xx	H, 32 bits	[°C]
	Identification number 1	8C 40, 79, xx xx xx xx	A, 32 bits	
	Complementary counter 1 totalizer	84 40, co co, xx xx xx xx	B, 32 bits	
	Complementary counter 1 totalizer stored at month - 1	C4 40, co co, xx xx xx xx	B, 32 bits	
	Complementary counter 1 totalizer stored at month - 2	84 41, co co, xx xx xx xx	B, 32 bits	
	Complementary counter 1 totalizer stored at month - 3	C4 41, co co, xx xx xx xx	B, 32 bits	
	Complementary counter 1 totalizer stored at month - 4	84 42, co co, xx xx xx xx	B, 32 bits	
	Complementary counter 1 totalizer stored at month - 5	C4 42, co co, xx xx xx xx	B, 32 bits	
	Complementary counter 1 totalizer stored at month - 6	84 43, co co, xx xx xx xx	B, 32 bits	
	Complementary counter 1 totalizer stored at month - 7	C4 43, co co, xx xx xx xx	B, 32 bits	
	Complementary counter 1 totalizer stored at month - 8	84 44, co co, xx xx xx xx	B, 32 bits	
	Complementary counter 1 totalizer stored at month - 9	C4 44, co co, xx xx xx xx	B, 32 bits	
	Complementary counter 1 totalizer stored at month - 10	84 45, co co, xx xx xx xx	B, 32 bits	
	Complementary counter 1 totalizer stored at month - 11	C4 45, co co, xx xx xx xx	B, 32 bits	
	Complementary counter 1 totalizer stored at month - 12	84 46, co co, xx xx xx xx	B, 32 bits	
	Complementary counter 1 totalizer stored at month - 13	C4 46, co co, xx xx xx xx	B, 32 bits	
	Complementary counter 1 totalizer stored at month - 14	84 47, co co, xx xx xx xx	B, 32 bits	
	More records in next telegram	mo		Start of manufacturer specific data
End	Check Sum	cs		
	Stop	16		


Rsp_4

	Field	Frame bytes in hex (Note 1)	Coding	Comment
Start	Start, Length	68, Le Le, 68		
	Control	08		Respond with user data, RSP_UD
	Address	xx		
User data	Control Information	72		Variable structure respond
	Identification number	xx xx xx xx	A, 32 bits	
	Manufacturer ID	EE 4D	C, 16 bits	"SON"
	Version of meter	00	C, 8 bits	
	Device type	dt	D, 8 bits	
	Access number	xx	C, 8 bits	
	Status	st	Ds, 8 bits	
	Signature (not used)	00 00	C, 16 bits	
	Identification number 2	8C 80 40, 79, xx xx xx xx	A, 32 bits	
	Complementary counter 2 totalizer	84 80 40, co co, xx xx xx xx	B, 32 bits	
	Complementary counter 2 totalizer stored at month - 1	C4 80 40, co co, xx xx xx xx	B, 32 bits	
	Complementary counter 2 totalizer stored at month - 2	84 81 40, co co, xx xx xx xx	B, 32 bits	
	Complementary counter 2 totalizer stored at month - 3	C4 81 40, co co, xx xx xx xx	B, 32 bits	
	Complementary counter 2 totalizer stored at month - 4	84 82 40, co co, xx xx xx xx	B, 32 bits	
	Complementary counter 2 totalizer stored at month - 5	C4 82 40, co co, xx xx xx xx	B, 32 bits	
	Complementary counter 2 totalizer stored at month - 6	84 83 40, co co, xx xx xx xx	B, 32 bits	
	Complementary counter 2 totalizer stored at month - 7	C4 83 40, co co, xx xx xx xx	B, 32 bits	
	Complementary counter 2 totalizer stored at month - 8	84 84 40, co co, xx xx xx xx	B, 32 bits	
	Complementary counter 2 totalizer stored at month - 9	C4 84 40, co co, xx xx xx xx	B, 32 bits	
	Complementary counter 2 totalizer stored at month - 10	84 85 40, co co, xx xx xx xx	B, 32 bits	
	Complementary counter 2 totalizer stored at month - 11	C4 85 40, co co, xx xx xx xx	B, 32 bits	
	Complementary counter 2 totalizer stored at month - 12	84 86 40, co co, xx xx xx xx	B, 32 bits	
	Complementary counter 2 totalizer stored at month - 13	C4 86 40, co co, xx xx xx xx	B, 32 bits	
	Complementary counter 2 totalizer stored at month - 14	84 87 40, co co, xx xx xx xx	B, 32 bits	
	More records in next telegram	mo		Start of manufacturer specific data
End	Check Sum	cs		
	Stop	16		

Note : See Supercal 531/449 M-Bus frames documentation for details

9. Annex D

9.1 Detailed writing process schematics



10. Annex E

10.1 Add entry to device list to write a device

		Identification Number	Manufacturer ID	Generation of Meter	Measured Media	Radio Address	Radio Device Type	Options	Maximal Frame Number	Application Reset Subcode	Date of Last Successful Reading
	Type	A	C	C	D	A	C	D	C	D	G
	Bytes	4	2	1	1	4	1	1	1	1	2
	Notes	a, e	a, e	a	a	b, e	b	b	b	b	c, e
Device type	Values to write										
HCA 502, 502S, 552	Set of values	xxxxxxxxh	4DEEh	4	08h	xxxxxxxxh	0	00h	00h	00h	0101h
540 pulses	Set of values	xxxxxxxxh	4DEEh	1	00h	xxxxxxxxh	2	00h	00h	00h	0101h
531 / 449	Set of values	xxxxxxxxh	4DEEh	12	04h	xxxxxxxxh	3	00h	00h	00h	0101h
539	Set of values	xxxxxxxxh	4DEEh	4	04h	xxxxxxxxh	1	00h	00h	00h	0101h
590 WCA	Set of values	xxxxxxxxh	38AFh	4	07h	xxxxxxxxh	4	01h	00h	00h	0101h
580 Water counter	Set of values	xxxxxxxxh	4DEEh	10	07h	xxxxxxxxh	4	00h	00h	00h	0101h
581 Water counter	Set of values	xxxxxxxxh	4DEEh	20	07h	xxxxxxxxh	4	00h	00h	00h	0101h
556 HCA	Set of values	xxxxxxxxh	4DEEh	16	08h	xxxxxxxxh	5	31h	00h	00h	0101h
541 pulses	Set of values	xxxxxxxxh	4DEEh	10	00h	xxxxxxxxh	6	10h	00h	00h	0101h

Notes

- a This value is part of the M-Bus secondary address used to access the data of a device stored in 636. It is updated by 636 according to the value really read from the device by radio.
- b This value is used to access the device by radio. It is never modified by the 636 itself.
- c The date 1.1.2000 means ""not yet successful read"", coded in M-Bus G type: 0101h
- e Multibytes values are transmitted with LSB first.

Options

bit7..0 Internal use

10.2 Writing standard products

	Field	Frame bytes in hex (Note 1)	Coding	Comment
Start	Start, Length	68, Le Le, 68		
	Control	73 53		Send user data to slave, SND_UD
	Address	FE		
User data	Control Information	51		Structured write telegram
		See product documentation		
End	Check Sum	cs		
	Stop	16		

To write a standard product (e.g. 580, 581, 590, 541, 539) send a standard command "SND_UD" as described in the respective M-Bus frames documentation.

10.3 Writing the heat cost allocator 502 / 552

	Field	Frame bytes in hex (Note 1)	Coding	Comment
Start	Start, Length	68, Le Le, 68		
	Control	73 53		Send user data to slave
	Address	FE		
User data	Control Information	51		Stuctured write telegram
	Select week in period A in 502/552	0F, 00, 57, 30, x1 x2 x3 x4 x5 x6	LVAR	§
End	Check Sum	cs		
	Stop	16		

You can select maximum 4 weeks in the year in period A.

Week N°1 : days 1..7; Week N°2 : days 8..15; Week N°3 : days 16..23; Week N°4 : days 24..31

	Week N°4	Week N°3	Week N°2	Week N°1	Week N°4	Week N°3	Week N°2	Week N°1
bit	7	6	5	4	3	2	1	0
Byte x1	february				january			
	x	x	x	x	x	x	x	x
Byte x2	april				march			
	x	x	x	x	x	x	x	x
Byte x3	june				may			
	x	x	x	x	x	x	x	x
Byte x4	august				july			
	x	x	x	x	x	x	x	x
Byte x5	october				september			
	x	x	x	x	x	x	x	x
Byte x6	december				november			
	x	x	x	x	x	x	x	x

Example : to select period A from 16 may to 15 june =>

x1..x6 = 00, 00, 3C, 00, 00, 00

	Week N°4	Week N°3	Week N°2	Week N°1	Week N°4	Week N°3	Week N°2	Week N°1	
bit	7	6	5	4	3	2	1	0	
Byte x1	february				january				=00h
	0	0	0	0	0	0	0	0	
Byte x2	april				march				=00h
	0	0	0	0	0	0	0	0	
Byte x3	june				may				=3Ch
	0	0	1	1	1	1	0	0	
Byte x4	august				july				=00h
	0	0	0	0	0	0	0	0	
Byte x5	october				september				=00h
	0	0	0	0	0	0	0	0	
Byte x6	december				november				=00h
	0	0	0	0	0	0	0	0	

10.4 Writing the heat cost allocator Sontex 556

FRAME PARAMETRIZE				
	Field	Frame bytes in hex (Note 1)	Coding	Comment
Start	Start, Length	68, Le Le, 68		
	Control	73 53		Send user data to slave
	Address	FE		
User data	Control Information	51		Stuctured write telegram
	Change param in 556	0F, 02, Param556	LVAR	§
End	Check Sum	cs		
	Stop	16		
FRAME FINALIZE PARAMETRIZE (always necessary)				
	Field	Frame bytes in hex (Note 1)	Coding	Comment
Start	Start, Length	68, Le Le, 68		
	Control	73 53		Send user data to slave
	Address	FE		
User data	Control Information	51		Stuctured write telegram
	Finalize param in 556	0F, 02, finalizeParam556	LVAR	§ (Always necessary)
End	Check Sum	cs		
	Stop	16		
Symbols				
‡ Function: 0=instantaneous, 1=maximum, 2=minimum, 3=during error state				
§ manufacturer specific VIFE				
Notes				
1. For non hexadecimal or lower case digits see the detailed description in the Keys sheet.				

Param556 in FRAME PARAMETRIZE

Param556 is a frame wrapped in SND_UD frame, it has also a similar header and footer. The "L" (length) and "CS"(checksum) bytes must be calculated.

Param556		68	L	L	68																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																						
----------	--	----	---	---	----	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--

PARAM: (one or more, order insignificant)

ID number

				lsb	msb
01	12	04	xx	xx	xx	xx	xx

BCD M-Bus format A

KC and KQ factor^[3]

								float M-Bus format H							
02	0E	81	20	FF	03	14	04	xx	xx	xx	xx	xx	xx	xx	xx
								KC				KQ			

Date and time

01	0C	04	xx	xx	xx	xx	xx
----	----	----	----	----	----	----	----

M-Bus format F

Set day

								lsb	msb
02	0E	81	02	FF	02	16	02	xx	xx

M-Bus format G
(year will be '00)

Two different periods

Summer period start date, Winter period start date

								Summer date	Winter date
			lsb	msb	lsb	msb			
0C	16	02	xx	xx	xx	xx	xx	xx	xx

M-Bus format G (year will be '00)

To disable this function, put the date 2000-01-01 into the 2 dates.

Reset max. heatsink temp.

0C	20	02	00	00	00	00	00
----	----	----	----	----	----	----	----

[3]

If KC or KQ = 0 then the device will count in "unit scale" mode.
Otherwise will count in "product scale" mode.

Example

[illegible]

10.5 Writing the radio pulse adapter 540

Structured write SND_UD (master to slave)

	Field	Frame bytes in hex (Note 1)	Coding	Comment
Start	Start, Length	68, 1e 1e, 68		
	Control	73 53		Send user data to slave
User data	Address	FE		
	Control Information	51		Stuctured write telegram
	Write param in 540	0F, 01, BLOCK	LVAR	\$
	Check Sum	CS		
	Stop	16		

Symbols

± Function: 0=instantaneous, 1=maximum, 2=minimum, 3=during error state

§ manufacturer specific VIFE


You must send a SND_UD separately for each BLOCK (A, B or C) and for each counter.

If you change the factor and initial value in "BLOCK A", you must send "BLOCK B" and "BLOCK C".

For example if you need to change everything in the 4 counters, you must send 12 SND_UD.

In "BLOCK A", you can change one or more parameters (ex. only unit), but the group of parameters must be preceded with "F0 01" and ended with "FF".

For counter 1



For counter 2




ID number
Medium
Unit
Factor and initial value

info string

F0	01																						
05	04	9E	40	lsb	sb1	sb2	msb	unsigned integer (0..999999999)															
05	03	A2	40	ch0	ch1	ch2	ascii char (always 3 chr complete with space ='20h')																
05	05	A5	40	ch0	ch1	ch2	ch3	ch4	ascii char (always 5 chr complete with space ='20h')														
05	0C	AA	40	lsb	sb1	sb2	sb3	sb4	sb5	sb6	msb	lsb	sb1	sb2	msb								
												factor is a float (double IEEE754)											
												init. value (unsigned int)											
05	18	B6	40	ch0	ch1	ch2	ch3	ch4	ch5	ch6	ch7	ch8	ch9	ch10	ch11	ch12	ch13	ch14	ch15	ch16			
												ch17	ch18	ch19	ch20	ch21	ch22	ch23	ascii char (always 24 chr complete with space ='20h')				
FF																							



	F0	01																
	05	04	08	02	00	00	00	00										
	05	04	1C	40	00	00	00	00										
	05	04	04	41	00	00	00	00										
	05	04	14	41	00	00	00	00										
	05	04	24	41	00	00	00	00										
	05	04	34	41	00	00	00	00										
	05	04	44	41	00	00	00	00										
	05	04	54	41	00	00	00	00										
	05	04	64	41	00	00	00	00										
	FF																	



	F0	01																
05	04	74	41	00	00	00	00											
05	04	84	41	00	00	00	00											
05	04	94	41	00	00	00	00											
05	04	A4	41	00	00	00	00											
05	04	B4	41	00	00	00	00											
05	04	C4	41	00	00	00	00											
05	04	D4	41	00	00	00	00											
05	04	E4	41	00	00	00	00											
05	04	F4	41	00	00	00	00											
	FF																	

For counter 3




ID number
Medium
Unit
Factor and initial value

info string

F0	01																				
05	04	6C	40	lsb	sb1	sb2	msb	unsigned integer (0..999999999)													
05	03	70	40	ch0	ch1	ch2	ascii char (always 3 chr complete with space ='20h')														
05	05	73	40	ch0	ch1	ch2	ch3	ch4	ascii char (always 5 chr complete with space ='20h')												
05	0C	78	40	lsb	sb1	sb2	sb3	sb4	sb5	sb6	msb	lsb	sb1	sb2	msb						
												factor is a float (double IEEE754)									
												init. value (unsigned int)									
05	18	84	40	ch0	ch1	ch2	ch3	ch4	ch5	ch6	ch7	ch8	ch9	ch10	ch11	ch12	ch13	ch14	ch15	ch16	
				ch17	ch18	ch19	ch20	ch21	ch22	ch23	ascii char (always 24 chr complete with space ='20h')										
FF																					



F0	01																
05	04	0C	02	00	00	00	00										
05	04	20	40	00	00	00	00										
05	04	08	41	00	00	00	00										
05	04	18	41	00	00	00	00										
05	04	28	41	00	00	00	00										
05	04	38	41	00	00	00	00										
05	04	48	41	00	00	00	00										
05	04	58	41	00	00	00	00										
05	04	68	41	00	00	00	00										
FF																	



F0	01																
05	04	78	41	00	00	00	00										
05	04	88	41	00	00	00	00										
05	04	98	41	00	00	00	00										
05	04	A8	41	00	00	00	00										
05	04	B8	41	00	00	00	00										
05	04	C8	41	00	00	00	00										
05	04	D8	41	00	00	00	00										
05	04	E8	41	00	00	00	00										
05	04	F8	41	00	00	00	00										
FF																	

For counter 4

BLOCK A

ID number
Medium
Unit
Factor and initial value

info string

BLOCK B

BLOCK C

F0	01																				
05	04	3A	40	lsb	sb1	sb2	msb	unsigned integer (0..999999999)													
05	03	3E	40	ch0	ch1	ch2	ascii char (always 3 chr complete with space =20'h)														
05	05	41	40	ch0	ch1	ch2	ch3	ch4	ascii char (always 5 chr complete with space =20'h)												
05	0C	46	40	lsb	sb1	sb2	sb3	sb4	sb5	sb6	msb	lsb	sb1	sb2	msb	factor is a float (double IEEE754)					
															init. value (unsigned int)						
05	18	52	40	ch0	ch1	ch2	ch3	ch4	ch5	ch6	ch7	ch8	ch9	ch10	ch11	ch12	ch13	ch14	ch15	ch16	ascii char (always 24 chr complete with space =20'h)
				ch17	ch18	ch19	ch20	ch21	ch22	ch23											

F0	01							
05	04	10	02	00	00	00	00	
05	04	24	40	00	00	00	00	
05	04	0C	41	00	00	00	00	
05	04	1C	41	00	00	00	00	
05	04	2C	41	00	00	00	00	
05	04	3C	41	00	00	00	00	
05	04	4C	41	00	00	00	00	
05	04	5C	41	00	00	00	00	
05	04	6C	41	00	00	00	00	
FF								

F0	01						
05	04	7C	41	00	00	00	00
05	04	8C	41	00	00	00	00
05	04	9C	41	00	00	00	00
05	04	AC	41	00	00	00	00
05	04	BC	41	00	00	00	00
05	04	CC	41	00	00	00	00
05	04	DC	41	00	00	00	00
05	04	EC	41	00	00	00	00
05	04	FC	41	00	00	00	00
FF							

CD



CE **Conformity according to R&TTE 1999/5/CE**

The detailed certificate of conformity you can find on our internet homepage:
sontex.ch

Technical Support

For technical support contact your local Sontex agent or Sontex SA directly.

Hotline Sontex:

@sontex.ch
+41 32 488 30 04

© Sontex SA 2008